

roborock F25ACE

roborock F25 ACE Wet Dry Vacuum Cleaner User Manual

Model: **F25ACE** | Brand: **roborock**

INTRODUCTION

This user manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your roborock F25 ACE Wet Dry Vacuum Cleaner. Designed for hard floors, this cordless vacuum mop combines powerful suction with advanced cleaning technologies to deliver a thorough and convenient cleaning experience. Please read this manual carefully before using the appliance and retain it for future reference.



Image: The roborock F25 ACE Wet Dry Vacuum Cleaner, showcasing its sleek design and cordless form factor.

SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance. This includes, but is not limited to:

- Read all instructions before using the appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.

- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without filter in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Unplug from outlet when not in use and before servicing.

WHAT'S IN THE BOX

Your roborock F25 ACE package includes the following components:

- Wet Dry Vacuum Cleaner Unit
- Charging Station
- Power Cord
- Floor Cleaning Solution
- Supplementary Washable Filter
- Maintenance Brush
- User Manual (this document)

Please Note :

1. 20000Pa: Based on internal testing carried out by the manufacturer according to IEC 62885-2:2021/5.11 standards.
2. Zero Tangle: Data sourced from SGS and Roborock's internal testing.
3. 60min: Based on internal testing carried out by the manufacturer under Eco mode.
4. 4413 sqft: Based on internal testing carried out by the manufacturer under Eco mode.
5. 4.92 inch: Based on internal testing carried out by the manufacturer.
6. 194° F: Based on testing carried out by TUV SÜD on Staphylococcus aureus, Candida albicans and Escherichia coli under default self-cleaning mode. Report number: 704012406928-00.
7. 0% Tangle Rate: Data sourced from SGS and Roborock's internal testing.
8. 30 Days: Based on internal testing carried out by the manufacturer.
9. Only support 2.4G WiFi.

Image: A visual representation of all items included in the roborock F25 ACE packaging.

SETUP

1. Assembly:

Carefully remove all components from the packaging. Insert the handle into the main body of the vacuum cleaner until it clicks securely into place.

2. Charging the Battery:

Place the vacuum cleaner on the charging station. Connect the power cord to the charging station and plug it into a wall outlet. The battery indicator lights will illuminate to show charging status. For first use, fully charge the battery, which typically takes approximately 4 hours.

3. Filling the Clean Water Tank:

Locate the clean water tank. Open the cap and fill the tank with clean tap water. You may add the provided roborock floor cleaning solution according to the instructions on its bottle. Close the cap securely and reinsert the tank into the vacuum cleaner.

4. Initial Check:

Ensure the dirty water tank is empty and properly installed. Verify that the roller brush and filter are correctly in place before operation.

OPERATING INSTRUCTIONS

The roborock F25 ACE is designed for intuitive operation. Follow these steps for effective cleaning:

Power On/Off

Press the power button located on the handle to turn the vacuum cleaner on or off. The device will start in its default cleaning mode.

Cleaning Modes

The F25 ACE offers multiple cleaning modes to suit various cleaning needs. Use the mode selection button to cycle through them:

- **Eco Mode:** For light cleaning and extended battery life.
- **Suction Mode:** For vacuuming liquids or dry debris without mopping.
- **Auto Mode:** The smart dirt detection sensor automatically adjusts suction power and water flow based on the detected dirt level.
- **Max Mode:** For tackling stubborn messes and heavily soiled areas with maximum power.




Image: Illustration of the four distinct cleaning modes available on the roborock F25 ACE, including Eco, Suction, Auto, and Max modes.

Smart Dirt Detection (DirTect Smart Sensor)

In Auto Mode, the integrated DirTect Smart Sensor detects dirt levels in real-time. This allows the vacuum cleaner to automatically adjust its suction power and water dispensing for optimal cleaning intensity across

different surfaces and varying degrees of mess.



Image: Diagram illustrating the DirTect Smart Sensor's ability to detect dirt levels and adapt cleaning performance.

180° Lie-Flat Design

The F25 ACE features a 180° lie-flat design, allowing the main unit to recline fully. This enables effortless cleaning under low-clearance furniture, beds, and other hard-to-reach areas, ensuring no hidden dust or debris is left behind. The powerful 20,000Pa suction is maintained even in the lie-flat position.




Image: The roborock F25 ACE demonstrating its 180° lie-flat capability for cleaning under furniture.

Dual Scrapers Roller Technology

Equipped with innovative dual scrapers, the F25 ACE effectively removes wastewater and prevents hair tangles on the roller brush. One scraper ensures efficient water removal, while the comb design captures hair, ensuring a streak-free and tangle-free cleaning experience.

roborock F25 ACE

Wet Dry Vacuum Cleaner

Smart, Smooth, Stainless



Image: A comparison showing the effectiveness of the roborock F25 ACE's dual scrapers roller technology against single scraper designs, highlighting improved wastewater removal and tangle prevention.

Triple Edge Cleaning

The F25 ACE is designed to clean right up to edges with less than 0.03 inches clearance. This feature ensures thorough cleaning along baseboards, stairs, and into corners, leaving no dirt or grime behind.





Image: The roborock F25 ACE demonstrating its triple edge cleaning capability, reaching close to walls and corners.


Automatic Cleaning Solution Dispenser

The vacuum cleaner features an auto-dispenser that adaptively dispenses cleaning solution based on the detected floor stains, optimizing cleaning efficiency and ensuring consistent results. A full dispenser can last up to 30 days of typical use.


Enhanced Smooth Maneuvering



Lower Water Tank



70° Swivel Design



AI Assistant Wheels

Image: The roborock F25 ACE's automatic cleaning solution dispenser, highlighting its adaptive dispensing feature.

Roborock App Control

Enhance your cleaning experience by connecting your roborock F25 ACE to the Roborock App via Wi-Fi (2.4 GHz only). The app allows you to tailor cleaning settings, monitor status, and access additional features for personalized cleaning routines.

Your browser does not support the video tag.

Video: A demonstration of how to use the Roborock App to control and customize settings for the Roborock F25 ACE vacuum cleaner.

Bi-Directional Self-Cleaning

The brush will rotate both forward and backward for many times, ensuring deeper self-cleaning.



Image: Screenshots of the Roborock App interface, showing options to tailor cleaning and monitor device status.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your roborock F25 ACE. Perform these tasks regularly:

Self-Cleaning Function

After each use, place the vacuum cleaner on its charging station and initiate the self-cleaning cycle. The F25 ACE uses 194°F (90°C) hot water to thoroughly clean the roller brush, effectively cutting through grease and grime. This process also includes bi-directional scrubbing for a deeper clean.

180° Flat Reach Design to Clean Hidden Areas

Effortlessly reclines fully to 180°, allowing for easy maneuvering under low areas to clean hidden dust.



Image: Visual representation of the hot water self-cleaning process for the roller brush, reaching 194°F.

Hot Water Self-Cleaning

194°F hot water self-cleaning can clean the brush roller to the greatest extent while ensuring safety.




Image: Diagram illustrating the bi-directional rotation of the brush during self-cleaning for enhanced effectiveness.

Hot Air Drying System

Following the self-cleaning cycle, the F25 ACE activates a 194°F hot air drying system to thoroughly dry the roller brush. This prevents odors and ensures the brush is ready for the next use. You can choose between a fast 5-minute flash drying mode or a quieter 20-minute drying mode.

No Reduced Suction Even 180° Lie-Flat



Image: Illustration of the 194°F hot air drying system, showing the airflow that dries the roller brush.

Emptying the Dirty Water Tank

After each cleaning session, remove the dirty water tank and dispose of the contents. Rinse the tank thoroughly with clean water to prevent residue buildup and odors. Ensure the tank is completely dry before reinserting it.

Cleaning the Filter

The F25 ACE features a washable filter. Periodically remove the filter, rinse it under running water until clean, and allow it to air dry completely before reinstallation. Do not use the vacuum without the filter properly installed and dry.

General Cleaning

Wipe down the exterior of the vacuum cleaner with a soft, damp cloth as needed. Do not use harsh chemicals or abrasive cleaners.

TROUBLESHOOTING

If you encounter issues with your roborock F25 ACE, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted; Power button not pressed correctly.	Charge the battery fully; Ensure the power button is pressed firmly.
Poor suction.	Dirty water tank full; Clean water tank empty; Clogged roller brush; Clogged filter.	Empty dirty water tank; Fill clean water tank; Clean roller brush; Clean or replace filter.
Leaves streaks on floor.	Dirty roller brush; Dirty water tank full; Incorrect cleaning solution ratio.	Run self-cleaning cycle or manually clean roller brush; Empty dirty water tank; Use recommended cleaning solution and ratio.
Unpleasant odor.	Dirty water tank not cleaned; Roller brush not dried properly.	Empty and rinse dirty water tank thoroughly; Ensure hot air drying cycle completes or manually dry roller brush.
Hair tangles on roller brush.	Excessive hair accumulation.	Run self-cleaning cycle; Use the maintenance brush to remove tangled hair from the roller.

If the problem persists after attempting these solutions, please contact roborock customer support for further assistance.

SPECIFICATIONS


Feature	Detail
Brand	roborock
Model Name	F25ACE

Feature	Detail
Special Features	Wet/Dry, Cordless, Foldable, Washable Filter, Bagless
Filter Type	Washable Filter
Included Components	Dusting Brush, Accessory Kit, Charging Dock, Floor Cleaning Solution, Supplementary Washable Filter, Maintenance Brush, User Manual
Capacity	0.74 Liters
Wattage	240 watts
Runtime	Up to 1 hour (60 minutes)
Charging Time	4 Hours
Recommended Uses	Pet Hair, Hard Floor Cleaning
Form Factor	Stick
Color	Black
Product Dimensions	10.3"L x 9.5"W x 43.3"H
Battery Type	Lithium-Ion (1 included)
Noise Level	75 dB
Control Method	App, Hand Control, Push Button
Connectivity	Wi-Fi (2.4 GHz only)
Item Weight	10.3 pounds
Country of Origin	China

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official roborock website. If you require technical support, have questions about your product, or need to arrange service, please contact roborock customer support through the channels provided in your product packaging or on their official website.

You can also visit the [Roborock Store on Amazon](#) for additional product information and accessories.



[Roborock F25 ACE Wet and Dry Vacuum Cleaner User Manual](#)

This user manual provides comprehensive instructions for the Roborock F25 ACE Wet and Dry Vacuum Cleaner, covering safety information, product introduction, installation, usage, maintenance, and troubleshooting.

lang:en score:35 filesize: 424.41 K page_count: 52 document date: 2024-11-13